



## Install and set up APP

Open folder 3\_APP and install " TSCINBUNY .apk " to your phone

 TSCINBUNY.apk	2022/7/27 17:51	APK 文件	2,697 KB
 安装和设置APP.docx	2023/10/23 17:53	DOCX 文档	3,059 KB

Next , we use an Android phone to demonstrate how to control the ZHIYI smart robotic arm car through this application :  
Enter the professional debugging interface and click the add button "+"



You need to fill in the project name for the project name.



Click OK to see the built project



Click on the project name and the options to modify the project will be displayed.



First configure the communication settings , click the "+" sign, add a Boolean value , and then enter the Boolean value name.





You can see that the created Boolean values will be displayed in this column. Use the same method to create 11 more Boolean variables. They are tracking, Avoid, follow, dungeon, save, auto, empty, claws\_open, claws\_closed, count-clockwise, clockwise



Click the "+" sign in the byte value column, add the byte value "byte", and then enter the byte value name



Take setting a variable X that controls the left and right movement direction as an example, and change the name to X






You can see that the created byte values will be displayed in this column. Use the same method to create 4 more byte value variables. respectively Y, speed, Base, Arm




Click the second option at the bottom to create two receive byte values, namely: Distance, Actions



After all the above are added, return to the layout " Edit Controls " to add controls .



Click the "+" sign in the upper right corner to create a new control, taking the slider control that controls speed as an example;



Select the data type to be connected and the variable values just set, byte and speed



Then set the upper and lower limits and click OK to complete;



Add another joystick control to control the direction of the car:




Select the connection data type byte and variable name X/Y , and then check the release automatic reset :



Add another same joystick control to control the opening and closing of the claws, and select Base and Arm as variables.

Add a text control to display the ultrasonic distance :




Use the same method to add Actions;





Next add a control button and click the green button in the upper right corner to link the data:



设定按下时的数值:

1


设定松开时的数值:

0

如果输入框中数据为空, 则在相应时刻变量值不会改变。

OK

Use the same method to add 11 more controls , namely: tracking, Avoid, follow, dungeon, save, auto, empty, claws\_open, claws\_closed, count-clockwise, clockwise. Please drag and place these controls according to your own convenience.



The functions of each icon button in the upper right corner of the screen:

- 1 Add various controls,
- 2 connection variables
- 3 means setting control parameters
- 4 is to delete the control
- 5 Exit the current control layout
- 6 Movement control
- 7 Zoom in and out controls
- 8 control rotation angle

When the controls are all adjusted, start connecting via Bluetooth, go to Device Connections and click Search.

Find " BT05 " and click "Add Device". If a password is required, enter the password as 1234 or 0000. (If you find that connecting to Bluetooth is slow in future use, first "forget" the Bluetooth in the phone settings. Then search for and connect to Bluetooth in the APP.)

"+" again




When a red "x" appears, it means the Bluetooth connection is successful :



After the connection is successful, click Start and operate the car :



The final operation interface is as follows



free: free control, tracking: line following, Avoid: obstacle avoidance, follow: follow, dungeon: dungeon mode

**Notice:**

In free mode, the ultrasonic detection distance can be displayed in real time, but in other modes it is not displayed in real time;

Other modes are automatically executed. If you want to stop, you need to switch back to free mode;

When operating, pay attention to observe that the servo motor cannot be left in an unfinished state for a long time to prevent heating and damage;

**Memory function operation:** (Every time a servo motor is controlled by remote control, an action must be saved, and a maximum of 19 steps can be recorded)

The initial robot arm state is remote controlled to state 1, press the save button to record 1;

When remote control from state 1 to state 2, press the save button to record 2;

Then remote control from state 2 to state 3, and then press the save button to record 3;

This goes back and forth until the end action. It should be noted that the end action must be consistent with the initial action, so that continuous and consistent actions can be maintained when the automation execution is started.